

PRODUCT DATA SHEET

RANGE: Fixing Kits

CODE: PL8

DESCRIPTION: First Fix Kit PL8

DIMENSIONS



INSTALLATION

- 1 Fix the **Marflow Shower PL8** on a noggin or brick/block wall.
- 2 Install 14.7mm copper hot and cold feed pipes ensuring they will protrude approximately 60mm from the finished wall surface.
- 3 Tighten up the clamping nuts.
- 4 Finish the wall with plaster and/or tiles.
- 5 Using a pipe slice, cut the copper pipes to ensure that the shower mixer cover plates meet the finished wall.
- 6 Flush the pipework.
- 7 Use the fittings supplied to install the shower mixer.



The perfect shower fixing for a quick 'first fix' install

Firmly clamps 14.7mm copper pipes accurately in place at 150mm centres

Supplied complete with brass fittings to connect to the majority of bar shower mixers

