## WORCESTER 🕲 BOSCH

**Greenstar 8000 Style** 

GR8700iW 35 C LPG

7738100840

The information provided fulfills the requirements of regulations (EU) 811/2013 and (EU) 813/2013.

Productdata	Symbol	Unit	7738100840
Condensing boiler			Yes
Low temperature boiler			No
B1 boiler			No
Cogeneration space heater			No
Equipped with a supplementary heater?			-
Combination heater			Yes
Rated heat output	Prated	kW	34
Seasonal space heating energy efficiency	η <sub>s</sub>	%	94
Energy Efficiency Class			A
Useful heat output			•
At rated heat output and high temperature regime	P <sub>4</sub>	kW	33,7
At 30 % of rated heat output and low temperature regime	P <sub>1</sub>	kW	11,3
Useful efficiency			L
At rated heat output and high temperature regime	η <sub>4</sub>	%	88,8
At 30 % of rated heat output and low temperature regime	η <sub>1</sub>	%	98,8
Auxiliary electricity consumption			•
At full load	elmax	kW	0,048
At part load	elmin	kW	0,013
In standby mode	P <sub>SB</sub>	kW	0,001
Other items	· · · ·		•
Standby heat loss	P <sub>stby</sub>	kW	0,071
Ignition burner power consumption	P <sub>ign</sub>	kW	0,000
Emissions of nitrogen oxides (only gas- or oil fired)	NO <sub>x</sub>	mg/kWh	25
Annual energy consumption (average climate conditions)	Q <sub>HE</sub>	kWh	-
Annual energy consumption	Q <sub>HE</sub>	GJ	60
Sound power level, indoors	L <sub>WA</sub>	dB	53
Additional data for combination heaters			1
Declared load profile			XL
Water heating energy efficiency	η <sub>wh</sub>	%	87
Water heating energy efficiency class			А
Daily electricity consumption (average climate conditions)	Q <sub>elec</sub>	kWh	0,168
Annual electricity consumption	AEC	kWh	37
Daily fuel consumption	Q <sub>fuel</sub>	kWh	22,174
Annual fuel consumption	AFC	GJ	18
Indication about ability working only during off-peak hours			No
Other load profiles			-
Standing loss	S	W	-
Storage volume	V	I	-
Non-solar storage volume (Vbu)	Vbu	I	-

Specific precautions for installation, maintenance as well as recycling and/or disposal are provided within the installation and operating manuals. Read and follow the installation and operating manuals.